## DOMINATOR PLUS E3407 BAIN MARIE

CAUTION: Read the instructions before using the appliance.



## **USERS INSTRUCTIONS**

SECTION 1 - GENERAL DESCRIPTION SECTION 2 - CONTROLS and OPERATION SECTION 3 - COOKING HINTS SECTION 4 - CLEANING and MAINTENANCE

This appliance has been UKCA/CE marked based on compliance with the relevant Electrical and Electromagnetic Compatibility (EMC) Regulations/Directives for the voltages stated on the data plate.

### IMPORTANT

# This appliance must only be installed by a competent person in compliance with the regulations in force at the time.

UK regulations are listed on the front of the Installation and Service Manual.

### PREVENTATIVE MAINTENANCE CONTRACT

To obtain maximum performance from this unit regular servicing of the appliance should be undertaken to ensure correct operation, it is functioning as intended, and safe to use. We recommend servicing in accordance with SFG20 Maintenance Schedules and as a minimum, after 2,500 hours of use, or annually, whichever comes first and that a maintenance contract be arranged with an appointed service contact. Visits may then be made at agreed intervals to carry out adjustments and repairs.

### WARNING - THIS APPLIANCE MUST BE EARTHED!

Upon receipt of this manual, the installer should instruct a responsible person (or persons) as to the correct operation and maintenance of the unit.

This equipment is designed FOR PROFESSIONAL USE ONLY and be operated by QUALIFIED persons. It is the responsibility of the supervisor or equivalent to ensure that the user wears SUITABLE PROTECTIVE CLOTHING. Attention should also be drawn to the fact that some parts of the appliance will, by necessity, become VERY HOT and could cause burns if touched accidentally.



### WEEE Directive Registration No. WEE/DC0059TT/PRO

At end of unit life, dispose of appliance and any replacement parts in a safe manner, via a licensed waste handler.

Units are designed to be dismantled easily and recycling of all material is encouraged whenever practicable.

**Falcon Foodservice Equipment** Head Office and Works Wallace View, Hillfoots Road, Stirling. FK9 5PY. Scotland. PHONE: 01786 455200

T100819 Ref.7

### SECTION 1 -GENERAL DESCRIPTION

The E3407 is a 400mm wide electric wet-well bain marie.

It is designed to be mounted on a worktop or similar surface. Alternatively, it can be installed upon a fixed or mobile stand.

Heating element is controlled by a single thermostat. A red neon indicates that power is available (i.e. isolating switch is on). The amber neon will go out when the set temperature has been reached.

This unit is designed to accommodate standard 1/1 gastronorm containers (530mm x 325mm) with a maximum depth of 150mm.

### Warning - THIS APPLIANCE MUST BE EARTHED.



### SECTION 2 -CONTROLS and OPERATION

The main purpose of a bain marie is to store hot food prior to serving. It is to maintain this food at a proper, safe, serving temperature without it drying out or otherwise detracting from cooked product quality.

The unit is fitted with a thermostat that enables water temperature of the well to be controlled in order to store food. A drain tap is situated at the front to drain water from the well as required.

It is advised that any food is kept in flanged catering containers that rest around the well edge.

The control knob is marked with graduated positions from 1 to 5. At ● position, detailed in Figure 1, the elements are turned completely OFF.



#### Figure 1

Fill the well with clean water to **at least** the **maximum level** marked on rear wall. Water should be topped up relative to depth of container. Ensure container base is in contact with the water in the well to enable warming.

**NOTE**: For shallow containers, water may require to be **above maximum level.** 

#### IMPORTANT - DO NOT OVERFILL. If an empty

container is placed upon the water it may float. Ensure that when cooked food is added to container, that water will not overflow over well sides.



**WARNING** – For 150mm deep gastronorm containers, water level should not exceed the **MINIMUM** level or it may overflow.

Turn control knob to Setting 4. Water will heat to approximately 90°C to maintain a safe holding temperature.

The setting can be adjusted depending on type of food, quantity of food, etc. Thick milky liquids such as custard and porridge usually require a lower heat setting than vegetables and scrambled egg.

#### **IMPORTANT NOTE**

Check water level every hour and top-up as necessary.



WARNING – NEVER LET THE WELL BOIL DRY.

NEVER, under any circumstances switch unit on without filling well with water or damage may occur.

Ensure lid is placed over container when keeping food hot for a prolonged time. When lid is removed for serving, increasing the setting can offset any extra loss of heat.

A drain valve is provided to empty the well after use. Ensure valve is closed before filling pan with water. Refer to Figure 2.

If the appliance boils dry under any circumstance, the safety thermostat may trip. This will stop amber neon and heating element from switching on until it has been reset.

To reset, first locate button below front panel. Press button using a thin blunt object, such as a short pen. Allow unit to cool down to continue normal operation.



**IMPORTANT** – If appliance still fails to heat up or safety thermostat continues to trip, call a qualified service engineer.



Figure 2

### **SECTION 3 - USING THE BAIN MARIE**

The following guidelines may be helpful for specific foods.

Type of Food	Thermostat Setting
Sliced roast meat (no gravy)	High - use shallow container.
Vegetables (carrot, onion, turnip, etc)	Moderate - if storing for lengthy periods add a small amount of hot water
Fish	High - use a greased shallow pan.
Stewed and braised meat	High - use shallow container.
Soup, gravy, sauces, etc.	Maximum - use a deep container.
Scrambled egg	Low - undercook eggs to prevent drying to prevent drying

### SECTION 4 -CLEANING and MAINTENANCE



IMPORTANT BEFORE ANY CLEANING IS UNDERTAKEN, DISCONNECT APPLIANCE BY UNPLUGGING FROM MAINS SUPPLY.

Clean food container(s) as soon as possible after use with hot water and detergent. Soap filled steel wool pads may be used to remove stubborn deposits.

After cleaning, empty water from pan via drain valve (at front) and wipe dry.



# WARNING - DO NOT ATTEMPT TO CLEAN THIS APPLIANCE WITH A JET OF WATER OR STEAM CLEAN.

Do not use proprietary cleaners, especially those with a high caustic content on unit surfaces. This is particularly important when appliance is hot. Such cleaners can cause serious damage or discolouration and only a soap or detergent solution should be used.

### SERVICE INFORMATION

This unit carries an extensive mainland UK warranty. The warranty is in addition to and does not change your statutory or legal rights.

The warranty policy can be found on our website which details the conditions of the warranty and the exclusions.

https://www.falconfoodservice.com/info-centre/policy



Service calls to equipment under warranty will be carried out in accordance with the conditions of sale.

Warranty calls can be made between 8:30 am and 5:00 pm weekdays only.

To ensure your warranty enquiry is handled as efficiently as possible, ensure you have the following appliance information prior to calling us:

- 1. Model number found on data plate
- 2. Serial number found on data plate
- 3. Brief description of the issue

To contact Falcon for a warranty issue dial (UK only) 01786 455 200 and select Warranty Issues from the menu.